

Mounting Instruction Wall Clock

The clock hands are not assembled for you because there is a risk of breaking during shipping. We have, however, provided you with detailed instructions on how to put it together.

Step 1: big hand

You will see some protruding clock work in the centre of the clock face. Place the big hand here and press until it fits tightly on the lower part, near the clock face.

Step 2: small hand

Proceed with the small hand: Stick it on top of the big hand - it will be tight on the upper half of the clock work.

Step 3: cover cap

Cautiously place the *cap (included in the bag)* on the clock work.

Important: There is a small metal pin poking out of the clock work. It needs to be inserted into the cover cap.



clock work



cover cap

